



$3/8''$

Full Overlay

A full overlay door means there is very little cabinet frame showing around each door and drawer front, creating a living space with a modern, seamless appearance.



$2''$

1/2" Overlay

Cabinetry designed with a 1/2" overlay door and drawer front leaves 2" of the cabinet frame exposed between the doors, creating a more traditional look.